

TRAVERFILL

Travertine Hole & Void Repair

Quickly repair unsightly holes, voids and pits in travertine surfaces. Easy-to-use. Leaves a matte finish. Available in Light and Dark colors for a perfect color match.



For Use On:
travertine

Available Sizes:
1lbs. & 3 lbs.

Available Colors:
Light & Dark

Coverage:
50 - 200 sq. ft. per pound

USES:

- Floors
- Countertops
- Backsplashes
- Walls

ADVANTAGES:

- Easy to use
- Replaces factory filler
- Match any color of travertine by mixing light and dark options
- Dries to a matte finish

Application Instructions:

1) Make sure surface is clean, dry, free of debris, waxes and/or coatings. **2)** Mix Traverfill powder in a bucket with clean water. For smaller holes, mix into a thinner consistency. For larger holes, mix into a slightly thicker consistency. (Only mix as much as can be used in 10 - 15 minutes) **3)** Apply Traverfill onto surface with a small putty knife or grout float. **4)** Allow Traverfill to completely dry on surface. This may require 10 - 15 minutes depending on area temperature and moisture. **5)** After Traverfill is completely dry, clean the excess Traverfill using a moist sponge.

NOTE: If the Traverfill is not completely dry when cleaning (step 5), the moist sponge may remove some Traverfill from the holes you just repaired.