



Diamond Impregnated Pads Specifically Designed for Stone Surfaces

ZOOM Diamond Impregnated Pads are the **CHEMICAL-FREE** solution for care and maintenance of natural stone and terrazzo. **JUST ADD WATER**. Simply use these pads with water and avoid all the risk of chemicals and inexperience.

If you or your customers are looking for an **ENVIRONMENTALLY FRIENDLY, EASY-TO-USE** alternative, the **ZOOM** System delivers the best results and ensures consistent performance. No chemicals, no powders, no slurry, **NO MESS**.



For Use On:

- marble
- travertine
- limestone
- terrazzo

Equipment:



Low-Speed Swing Machines



Automatic Scrubbers

Available Sizes:

5\", 7\", 12\" 13\" 14\" 16\" 17\" 19\" & 20\"

PRODUCT FEATURES:

- Chemical-Free Cleaning
- Available in any size
- Cost Effective
- Only needs water
- Packaged for easy identification of grit, size and quantity

ADVANTAGES:

- For use on both swing machines and auto-scrubbers
- Less mess and easy clean up
- Easy-to-Use
- Lower Labor Costs
- Eco-Friendly

**MADE
IN THE USA**

HOW IT WORKS

Deep scratches to high shine, grits for any job

200

The most aggressive grit available. Designed for removal of moderate scratch damage. Ideal for maintenance on non-polished (honed) marble, travertine and limestone surfaces.

400

Removes moderate to light scratches and stains leaving a clean matte finish.

800

Removes fine surface scratches and light stains leaving a smooth slightly reflective finish.

1,500

Cleans and prepares floor for a high polish. Brings back luster and can also be used for periodic maintenance where scratch removal is not necessary.

3,000

Cleans and leaves floor with a high polish. Can be used as a daily maintenance pad.

8,000

Adds additional shine when used after conventional abrasive polishing steps.

11,000

Yields a super high gloss finish on floors that have been treated with prior steps or conventional abrasive polishing steps. Can be used as a daily maintenance pad.



Directions for use: Wet

Make sure floor is free of any debris and/or coatings. Mount the appropriate ZOOM pad onto the pad driver with ZOOM logo upwards towards the pad driver.

ZOOM pads are designed to be used with water. Clean/rinse pads with water after each use.

SCAN
TO VIEW
HOW-TO
VIDEO

